



45 AMP COOKER SWITCH

WARNING Never take risks with electrical safety. Always disconnect the mains power before beginning any electrical work and test that it is isolated - it is NOT enough just to turn off the light switch. Electrical products must be installed in accordance with IET regulations (BS 7671). If you are in any doubt, always consult a qualified electrician or an experienced person registered with an electrical Competent Person Scheme. Further information is available online or from your Local Authority. If the lighting circuit is not protected by a Residual Current Device (RCD) then the installation should be carried out and tested by a qualified electrician. If necessary, use a suitable stepladder, but first read the useful advice given by the Health and Safety Executive. Visit www.hse.gov.uk and search for 'using stepladders'.


Your 45 amp cooker switch

Your 45 amp cooker switch is suitable for indoor use only; it fits a standard UK double gang wall box. The wall box should have a minimum of 35mm depth to allow enough space for connections once the socket is screwed into place.

Note: This product must be installed in accordance with local building regulations.


IMPORTANT: If you are in any doubt, STOP and seek professional help. Do not proceed unless you are sure.

Remove the front cover from your switch. Insert a small flat blade screwdriver into one of the base slots and carefully prise off the front cover.



To fit your 45 amp cooker switch

- 1 Ensure that the mains supply to the circuit is isolated.
- 2 Remove the two screws securing the existing socket.
- 3 Take a photo of the connections to its terminals. There should be two sets (Live, Neutral and Earth) of wires; one set are the supply and the other set leads to the load being powered. You need to determine which is which and connect them to the new switch accordingly.
- 4 Disconnect the wires from the existing switch and remove it from the installation.
- 5 Connect the wires to your new switch in the same way that they were connected to the previous switch.
- 6 Ensure that the bare copper earth connections have green/yellow sleeves to isolate them from other connections. Check that screw terminals are properly tightened and no bare wires are visible.
- 7 Secure the switch in place and test it.



| Connection | Old wire colours | New wire colours | Diagram shading |
|-------------|------------------|------------------|-----------------|
| Live (L) | Red | Brown | |
| Neutral (N) | Black | Blue | |
| Earth (⊕) | Green | Green/Yellow | |